



BEAM CLIP (TYP) SEE DETAIL TO THE RIGHT

DETAIL (CP)

SEE BEAM CLIP INSTALLATION PROCEDURE. SET BEAM CLIP WITH SET SCREW ON TOP OF BEAM FLANGE AND CLAMPING SURFACE UNDER DECK RIB. PUSH CLIP AGAINST DECK AND BEAM FLANGE WITH SET SCREW AS FAR ONTO BEAM FLANGE AS POSSIBLE. WHILE KEEPING BEAM CLIP VERTICAL, TURN SET SCREW TO SNUG TIGHT WITHOUT BURROWING INTO STEEL BEAM FLANGE. THEN PROCEED TO TURN SET SCREW 3/4 TURN (270°). TIGHTEN LOCK NUT MAKING SURE THAT BEAM CLIP REMAINS IN POSITION.

LAWRENCE R. PILON/ PROFESSIONAL ENGINEER
51 MAPLEVIEW DRIVE/PENNELVILLE, NY 13132
(315) 668-0039

MCGEE CORPORATION 12701 East Independence Blvd. P.O. Box 1375 Matthews, NC 28106-1375 Phone: (704) 882-1900 Telex: (800) 528-5589	PR. JOB NO.	FINAL JOB NO.	DRAWING NO.
		56128	P056128C
	RACETRAC PETROLEUM INC #1201 PEACHTREE PKWY & ENGINEERING DR PEACHTREE CORNERS, GA 30010 (WINNETT)		
SCALE: NTS	IN ACCORDANCE WITH REV. LETTER:	DRAWN BY: JWG	
DATE: 2/13/18		CHK'D BY:	
THESE PRINTS ARE THE PROPERTY OF MCGEE CORP. REPRODUCTION OR REUSE IS PROHIBITED WITHOUT WRITTEN PERMISSION.			
METAL CANOPY 30'-0" x 193'-0"			SHEET NO. 4 OF 4
MISC. DETAILS			