



DETAIL CP1
REV 02-21-19

McGEE BEAM CLIP INSTALLATION PROCEDURE: SET BEAM CLIP WITH BOLT ON TOP OF BEAM FLANGE AND CLAMPING SURFACE UNDER DECK RIB. PUSH CLIP AGAINST DECK AND BEAM FLANGE WITH BOLT AS FAR ONTO BEAM FLANGE AS POSSIBLE. WHILE KEEPING BEAM CLIP VERTICAL, TURN BOLT TO SNUG TIGHT WITHOUT BURROWING INTO STEEL BEAM FLANGE. THEN PROCEED TO TURN BOLT 3/4 TURN (270'). TIGHTEN LOCK NUT MAKING SURE THAT BEAM CLIP REMAINS IN POSITION.

DETAIL TC1
REV.3 11-11-98

DETAIL PH24
REV 05-14-96

DETAIL WP4
REV.3 11/09/00

LAWRENCE R. PILON/ PROFESSIONAL ENGINEER
51 MAPLEVIEW DRIVE/PENNSVILLE, NY 13132
(315) 668-0039

McGEE CORPORATION 12701 East Independence Blvd., P.O. Box 1375 Matthews, NC 28108-1375 Phone: (704) 882-1500 Fax: (800) 528-5589	PIR. JOB NO. P057358-B FINAL JOB NO. P057358-B DRAWING NO. P057358B	RACETRAC STATION #1304 839 LOGANVILLE HWY BETHLEHEM, GA 30620 (BARROW) SCALE: 3/16"=1'-0" DATE: 9/30/2019 IN ACCORDANCE WITH REV. LETTER:	DRAWN BY: SBL CHECKED BY: SHEET NO. 3 OF 3
	METAL CANOPY 30'-0" x 70'-4" DETAILS		

