


1 CODE PLAN
 A003 1/8" = 1'-0"



LEGEND	
	EMERGENCY LIGHT FIXTURE
	WALL MOUNTED ILLUMINATED EXIT SIGN PER ELECTRICAL
	FIRE EXTINGUISHER CABINET (CLASS 2A-10B; C MIN.) MOUNT @ 48" AFF TO CENTER OF UNIT. VERIFY TYPE AND LOCATION PRIOR TO INSTALLATION
	FIRE EXTINGUISHER. MOUNT @ 48" AFF TO CENTER OF UNIT. VERIFY TYPE AND LOCATION WITH FIRE MARSHALL PRIOR TO INSTALLATION
	EXIT PATH

- GENERAL NOTES**
- ACCESS CONTROL SYSTEM SHALL NOT REQUIRE KEYS, TOOLS, OR SPECIAL KNOWLEDGE TO OPERATE DOORS OR LOCKS WHEN TRAVELING IN THE DIRECTION OF EGRESS.
 - ACCESS CONTROL SYSTEM SHALL ALLOW NORMAL AND EMERGENCY EGRESS THROUGH DOORS AT ALL TIMES.
 - SEE ELECTRICAL FOR EMERGENCY LIGHTING.
 - ALL ACCESSIBLE CLEARANCES ARE TYPICAL ON PLAN.
 - AS PER CODE ADDRESS NUMBERS ARE TO BE PLAINLY LEGIBLE AND VISIBLE FROM THE STREET OR ROAD WITHIN 5 FEET OF THE MAIN ENTRANCE TO THE BUILDING. NUMBERS SHALL CONTRAST WITH THEIR BACKGROUND. NUMBER SHALL BE A MINIMUM OF 6" HIGH WITH A MINIMUM STROKE WIDTH OF .5 INCH.
 - FIXTURES SHOWN ARE FOR REFERENCE ONLY TO BE VERIFIED AND COORDINATED WITH WEST MARINE.
 - CONTRACTORS WILL SUBMIT FIRE ALARM AND FIRE SPRINKLER PLANS FOR CODE COMPLIANCE REVIEW TO OBTAIN SEPARATE PERMITS. IF TENANT IMPROVEMENTS REQUIRES SUBMITTAL.
 - VERIFY PORTABLE FIRE EXTINGUISHERS ARE PROVIDED. LOCATED AND MOUNTED PER LOCAL FIRE CODES AS REQUIRED.
 - EXISTING EXIT SIGNS TO REMAIN. COORDINATE ANY CHANGES WITH FIRE MARSHALL IF REQUIRED.
 - SEE A001 FOR OCCUPANT LOAD AND EGRESS CALCULATIONS AND MAXIMUM ALLOWABLE TRAVEL DISTANCE.

Order Plans @