HEATING HOT WATER COIL OERATIONS AND SPECIFICATIONS

THE HOU'S HEAT RECLAIM COIL SHALL PROVIDE HEAT FOR SPACE HEATING AND SUPPLY AIR (SA) REHEAT DURING DEHUMIDIFICATION OPERATIONS. HEAT REJECTED BY THE REFRIGERATION SYSTEM GENERATE THE HEAT NEEDED TO HEAT THE ZONE OR REHEAT THE DEHUMIDIFIED AIR. THE REFRIGERATION SYSTEM'S HEAT OF REJECTION IS CAPTURED BY A HEAT EXCHANGER AND TRANSPORTED TO THE HOT WATER COIL BY A CLOSED, SECONDARY HYDRONIC SYSTEM.

WHENEVER THE O/A DB DROPS BELOW 61 DEGREES F., AND ZONE'S TEMPERATURE DROPS BELOW 70 DEGREES F.,OR WHEN OPERATING IN THE DEHUMIDIFICATION MODE AND THE ZONE'S DB TEMPERATURE IS BELOW 74 DEGREES F., THE EMS SHALL ENABLE THE HEATING HW PUMP TO CIRCULATE HW THROUGH THE HEATING HW LOOP. THE LOOP SHALL REMAIN OPERATIONAL AS LONG AS THERE IS A CALL FOR HEATING FROM ANY R/TU OR O/A DB IS 60 DEGREES F. AND BELOW. THE SECONDARY HYDRONIC SYSTEM'S PUMP SHALL SECURE WHEN THE CALL FOR HEATING / REHEAT FROM ALL ZONE'S AND/OR THE O/A DB EXCEEDS 60 DEGREES F.

THE R/TU'S CONTROLLER SHALL MAINTAIN ZONE'S HEATING SETPOINT (70~-0.5F.) OR ZONE'S DEHUMIDIFICATION SETPOINT (74F.) BY MODULATING THE HOT WATER COIL 3-WAY VALVE. WHEN THE ZONE'S HEATING REQUIREMENTS ARE MET THE VALVE WILL CLOSE AND THE CONTROLLER SHALL SIGNAL THE EMS.

1. AC-1 - PROVIDE MOTORIZE 2 IN, 3-WAY BALL TYPE CONTROL VALVE AND SPRING RETURN, PROPORTIONAL 24V ACTUATOR WITH NEMA 2 HOUSING AND LISTED IN ACCORDANCE WITH UL 873. "BELIMO B359 SERIES, 2 IN. SS BALL AND STEM WITH BRASS BODY, CHARACTERIZED CONTROL VALVE (Cv= 57); WITH BELIMO AF24-US, 24VDC ACTUATOR" OR APPROVED EQUAL
2. COMBINATION AUTOMATIC FLOW LIMITING VALVE AND BALL VALVE WITH UNION. THE VALVE'S FLOW CARTRIDGE SHALL ALLOW FOR REMOVAL WITH IN-LINE BREAKING MAIN PIPING AND MAINTAIN FLOW WITHIN 5 PERCENT OF THE TOTAL FLOW. THE BALL VALVE SHALL HAVE A LARGE DIAMETER PLATED BALL WITH A FULL SIZE HANDLE AND A BLOWOUT PROOF STEM WITH A BRASS PACKING NUT. THE UNION SHALL HAVE AN EPDM "O" RING. B&G MODEL #AC 2" NPT CIRCUIT SENTRY OR APPROVED EQUAL
3. COMBINATION BALL VALVE AND WYE STRAINER WITH HOSE END DRAIN AND UNION. THE STRAINER SHALL HAVE A 20 MESH STAINLESS STEEL SCREEN AND A FORGE BRASS END DRAIN WITH A 3/4IN HOSE CONNECTION. THE BALL VALVE SHALL HAVE A LARGE DIAMETER PLATED BALL WITH A FULL SIZE STEEL HANDLE AND A BLOWOUT PROOF STEM WITH A BRASS PACKING NUT. THE UNION SHALL HAVE AN EPDM "O" RING. B&G MODEL #UBY OR APPROVED EQUAL
4. BRASS UNION WITH PRESSURE/TEMPERATURE PORT AND AIR VENT PORT. B&G MODEL #UA OR APPROVED EQUAL
5. CONTINUOUS AUTOMATIC AIR VENT WITH A BRASS BODY AND A 1/4IN NPT CONNECTION. B&G MODEL #97 OR APPROVED EQUAL
6. ISOLATION BALL VALVE WITH UNION. THE BALL VALVE SHALL HAVE A LARGE DIAMETER PLATED BALL WITH A FULL SIZE HANDLE AND A BLOWOUT PROOF STEM WITH A BRASS PACKING NUT. THE UNION SHALL HAVE AN EPDM "O" RING.
7. 4 1/2" SS STEM MOUNTED PRESSURE GUAGE, BRASS PRECISION GEAR & PISTON MOVEMENT, PUSH-IN LEXAN WINDOW, 0~60 PSI RANGE, BRASS SOCKET AND 1/4" MALE NPT THREAD, ACCURACY 1%, 1/4" BRASS BODY PRESSURE TEST PLUG W/ NORDEL PLUG CORE. WEBS #CTS-060 PRESSURE GUAGE, WEBS BPG-AIR TEAT PLUG OR APPROVED EQUAL
8. WEBS BIMETAL THERMOMETER WITH 3"DIAL, 304 SS CASE AND GLASS WINDOW, ACCURACY 1% OF READING, RANGE 0-250 F, AND EXTENSION NECK THERMOWELL WEBS 38M525 DIAL THERMOMETER WITH WEBS 825-75BS THERMOWELL OR APPROVED EQUAL





CONTROL LEGEND

- UNION
- UNION W/REDUCER
- THERMOMETER
- GLASS THERMOMETERS
- PRESSURE GUAGE
- BALL VALVE
- FLOW LIMITER
- UNION W/ AUTO AIR VENT TEMPERATURE& PRESSURE PORTS
- THREE WAY MOTORIZED CONTROL VALVE
- EMS ANALOG OUTPUT
- STRAINER W/TEMPERATURE & PRESSURE PORTS
- ROOM TEMPERATURE SENSOR

1 M6.1 HVAC - A/C HOT WATER HYDRONIC SYSTEM
SCALE:NTS

MELINK SYSTEM SEQUENCE OF OPERATIONS

DESCRIPTION & SETUP:

THIS SYSTEM WILL CONTROL THE EXHAUST AND SUPPLY AIR REQUIREMENTS FOR HOODS GH-1 AND GH-2. OPTICAL AND HEAT SENSORS IN THE HOODS AND EXHAUST DUCTS TRANSMIT COOKING ACTIVITY/INTENSITY TO THE SYSTEM I/O PROCESSOR MOUNTED IN THE UTILITY CABINET ON THE RIGHT SIDE OF GH-1. VARIABLE FREQUENCY DRIVES (VFD'S) HOUSED IN THE HOOD'S UTILITY CABINET WILL MODULATE F-1, F-2, MAU-1, AND MAU-2. A SEPERATE 1HP 208V VFD CONTROLLER WILL CONTROL EACH F-1, F-2, MAU-1, AND MAU-2. THE AVERAGE EXHAUST RATE SIGNAL SHALL BE USED TO CONTROL MAU-1 AND MAU-2, AND AS THE MODULATE AC-1'S OA DAMPER.

THE MELINK I/O PROCESSOR SHALL RECEIVE START AND STOP SIGNALS TO ACTIVATE THE SYSTEM'S GREASE HOODS. THE SIGNALS SHALL BE CONSISTENT TO THE STORE'S OPERATING HOURS. THE SYSTEM'S KEYPAD, MOUNTED ON THE LEFT SIDE OF GH-1 OR ON THE WALL WITHIN 10FT OF THE HOOD, WILL MONITOR AND DISPLAY THE EXHAUST HOOD'S PERFORMANCE. THE CONTROLLER SHALL HAVE A SWITCH TO OPERATE THE TIMED BYPASS FOR OFF HOURS OPERATIONS AND SYSTEM MAINTENANCE. THE HOOD'S BYPASS TIME PERIOD SHALL BE SET FOR 1 HOUR (ADJUSTABLE).

START-UP:

UPON ACTIVATION THE MELINK'S I/O PROCESSOR SHALL:

1) ACTIVATE THE GREASE HOOD LIGHTING SYSTEM,
2) INITIATE MONITORING OF THE OPTICAL AND HEAT SENSORS

OPERATION:

THE MELINK CONTROLLER WILL RECEIVE 0-10 V SIGNALS FROM THE OPTICAL AND HEAT SENSORS IN THE HOOD AND EXHAUST DUCT FROM EACH HOOD. AS THE COOKING LOAD INCREASES OR DECREASES THE CONTROLLER SHALL:

1) ADJUST THE GREASE FAN'S VFD'S AS NECESSARY TO MATCH THE FAN'S OUTPUTS TO THE COOKING LOAD. THE EXHAUST CFMS SHALL VARY FROM THE MAXIMUM TO THE MINIMUM SCHEDULED VALUES. SEE THE FAN SCHEDULE ON SHEET M-3.1.

2) THE MAKE-UP AIR FANS INITIATES OPERATION AT THEIR MAXIMUM CFM AND THEN ADJUST AS NECESSARY TO MEET THE REQUIREMENTS OF THEIR RESPECTIVE GREASE HOOD. SEE THE FAN SCHEDULE ON SHEET M-3.1 FOR THE MAXIMUM AND MINIMUM OUT SIDE AIR QUANTITIES

THE MELINK CONTROLLER SHALL CONTINUOUSLY MONITOR THE GREASE HOODS UNTIL THE END OF THE PROGRAMMED OPERATING PERIOD. AT THE END OF THIS TIME PERIOD THE CONTROLLER SHALL SECURE THE EXHAUST AND MAKE UP AIR FANS AND SEND A SIGNAL TO AC-1 TO CLOSE THE OA DAMPER.

BYPASS CONTROLS:

IN CASE OF AN EMERGENCY A 100% SWITCH ON THE KEYPAD WILL BYPASS THE SENSORS AND OPERATE THE FANS AT FULL SPEED TO 10 MINUTES (PROGRAMMABLE).

THE KEYPAD'S FAN SWITCH SHALL OPERATE AS A TIMED BYPASS FOR ACTIVATING GH-1 AND GH-2 DURING OFF HOUR OPERATIONS. WHEN ACTIVATED THE HOODS SHALL OPERATE NORMALLY EXCEPT POWER WILL BE SECURED AFTER A 1 HOUR PERIOD (PROGRAMMABLE).

THE I/O PROCESSOR SHALL MONITOR THE GRESE HOOD'S FIRE DETECTION SYSTEM. IN EVENT OF A GREASE HOOD FIRE THE MELINK'S I/O PROCESSOR SHALL SECURE THE SUPPLY AIR FAN, SF AND RE-ADJUST THE GREASE HOOD EXHAUST FANS VFDs TO RUN AT 100%.

FOR MELINK SYSTEM OPERATION DURING A GREASE HOOD FIRE SEE THE ANSUL SYSTEM SEQUENCE OF OPERATION ON SHEET M2.2



2 M6.1 HVAC - GH-1, GH-2 CONTROLS
SCALE:NTS

AC-1 SEQUENCE OF OPERATIONS

AC-1 IS A SEASONS-4 DUAL PATH ROOFTOP DX AIR CONDITIONING SYSTEM DESIGNED TO MONITOR, CONDITION AND DISTRIBUTE AIR TO THE PUBLIX SUPERMARKET SALES AREA. THE UNIT HAS TWO AIR PATHS, AN OUTDOOR AIR (OA) CIRCUIT, WHICH BRINGS IN OUTDOOR AIR AND EXHAUSTS RETURN AIR, AND RETURN AIR (RA) CIRCUIT, WHICH AIR CONDITIONS ZONE RECIRCULATED RA. THIS SYSTEM SHALL HAVE TWO MODES OF OPERATION, OCCUPIED AND UNOCCUPIED MODES. DURING THE OCCUPIED MODE THE OA DAMPER SHALL MODULATE TO MAINTAIN A MINIMUM CFM OF OA AS SCHEDULED. DURING THE OA PRE-SART THE OA CIRCUIT, SIMULTANEOUSLY, THE SUPPLY AIR FAN WILL RAMP UP TO THE MAXIMUM CFM (AS SCHEDULED). IN THE UNOCCUPIED MODE THE OA DAMPER WILL CLOSE AND THE DAMPER CONTROL SHALL OPEN THE UNIT'S INTERNAL RA BYPASS DAMPER, DIRECTING A PROTION OF THE RA THROUGH THE OA CIRCUIT. THE SUPPLY AIR FAN SHALL MODULATE CLOSED.

UNIT DISCRIPTION

COOLING IS ACCOMPLISHED USING FIVE (5) DIRECT EXCHANGE (DX) R-410A COMPRESSORS AND THREE (3) SEPERATE COOLING COILS. THE OUTSIDE AIR CIRCUIT INCORPORATES TWO (2) OF THE THREE COOLING COILS AND THREE (3) COMPRESSORS (TANDEM SET OF 2.5 OR 7.5 HP COMPRESSORS AND ONE (1) 13 OR 15 HP COMPRESSOR). WHILE THE RA CIRCUIT USES ONE (1) COOLING COIL AND A TANDEM SET OF 5.5 OR 8.0 HP COMPRESSORS.

THE FIRST COOLING COIL, THE DEHUMIDIFICATION COIL IN THE OA CIRCUIT IS PAIRED WITH A TANDEM SET OF 2.5 OR 7.5 HP COMPRESSORS. THE TANDEM SET CONSISTS OF A FIXED SCROLL COMPRESSOR (COMP #1A) OF THE TANDEM SET IS A DIGITAL SCROLL COMPRESSOR, WHICH ACTIVATES FIRST TO VARY REFRIGERANT FLOW IN ORDER TO MAINTAIN A CONSTANT OA CIRCUIT LEAVING AIR TEMPERATURE (LAT). COMP #1A AND ITS ASSOCIATED COOLING COIL CIRCUIT IS LABLED COIL 1A. THE SECOND TANDUM COMPRESSOR (COMP #1B) IS A CONSTANT SPEED COMPRESSOR WHICH MAXIMIZES SYSTEM CAPACITY. COMP #1A AND ITS ASSOCIATED COOLING COIL COMBINATION IS LABLED COIL 1B.

THE SECOND COIL (COOL & PRECOOLING COIL) EMPLOYS A 13 OR 15 HP COMPRESSOR (COMP #2) TO PRECOOL THE AIR DURING PEAK LOADS.

THE OA CIRCUIT DEHUMIDIFICATION COIL, CONSISTING OF COOL#1A & COOL#1B CIRCUITS, SHALL BE CONTROLLED TO MEET A VARIABLE LAT SETPOINT BASED ON THE ZONE'S DEWPOINT (DP). THE CONTROLLER SHALL ADJUST THE LAT_{SP} TO RANGE BETWEEN 45°F TO 70°F. IF THE DP_{ZONE} IS ABOVE THE DP_{SP} BY 3°F. OR MORE THE CONTROLLER SHALL LOWER THE COIL #1A LAT WILL ADJUST THE SETPOINT TOWARDS 45°F. HOWEVER, SHOULD THE DP_{ZONE} RISE ABOVE THE ZONE'S DP_{SP} WITH THE DP_{ZONE} BELOW ZONE'S DP_{SP} THE LAT_{SP} OF COIL #1A SHALL ADJUST TOWARDS 70°F.

COMPRESSOR #1A (A DIGITAL SCROLL COMPRESSOR) SHALL VARY THE FLOW OF THE REFRIGERANT THROUGH COIL #1A TO MAINTAIN THE OA CIRCUIT'S LAT_{SP}. THE CONTROLLER SHALL MONITOR THE OA CIRCUIT'S LAT_{SP}. THE ERROR SIGNAL, WHICH HARES PROMPTED BASED ON MINIMUM CAPACITY TO Z (0)% (0)% CAPACITY), IS GENERATED BY THE CPC 1684C CONTROLLER ALGORITHM TO ADJUST COMP #1A SPEED AS NEEDED. IF COMP #1A CAPACITY REMAINS BELOW 20% (ADJ.) FOR A DURATION OF 3 MINUTES (0 TO C) WITH BOTH COMP 1A AND 1B ENABLED THE CONTROLLER SHALL ADJUST THE MINIMUM CAPACITY LOWER TO 20% (2 (ADJ.). THE ABSOLUTE MINIMUM CAPACITY SHALL BE SET HIGHER THAN THE COMPRESSOR'S ABSOLUTE MINIMUM CAPACITY OF 10% (1 (ADJ)) FOR THE PROTECTION OF THE SYSTEM.

THE THIRD COIL (COOL #2, RA COIL) IS SUPPLIED REFRIGERANT THROUGH A TANDEM SET OF 5.5 OR 8.0 HP COMPRESSORS (COMP #2A, COMP #2B) TO AIR CONDITION ZONE RA WHEN THE OA CIRCUIT COOLING CAPACITY IS NOT CAPABLE OF MEETING THE ZONE'S TOTAL COOLING LOAD.

AC-1 USES A HOT WATER (HW) HEATING COIL TO PROVIDE REHEAT DURING DEHUMIDIFICATION MODE AND SPACE HEATING DURING THE HEATING MODE. THE HEATING HW COIL'S HEATING SOURCE IS EITHER TO THE SHA THE REFRIGERATION SYSTEMS HEAT RECLAIM HEAT EXCHANGER (RECLAIM) OR SUPPLEMENTARY HEATING IS PROVIDED BY AN ELECTRIC HEATING COIL FOR FLORIDA STORES OR A MODULATING GAS HEATER FOR NON-FLORIDA STORES.

THE SA IS PROVIDED BY AN APPOIL, SINGLE WIDTH SINGLE INLET 2019 FUENUM FAN PI PHA VARIBLE FREQUENCY DRIVE CONTROLLER. THE UNIT SHALL BE CONTROLLED BY A CPC MULTIFLEX 1684C BOARD. THE STARTISTOP SIGNAL IS PROVIDED BY THE BOARD'S DIGITAL OUTPUT #1.

OCCUPIED MODE

THE OCCUPIED MODE SHALL CORRESPOND TO THE OPERATING HOURS OF THE STORE. AT THE START OF THE OCCUPIED PERIOD THE CONTROLLER SHALL TAKE THE FOLLOWING ACTIONS:

1. A FAN'S VFD SHALL RAMP UP TO MAXIMUM CFM (AS SCHEDULED)
2. THE UNIT'S RA BYPASS DAMPER SHALL CLOSE

THE OCCUPIED MODE HAS FOUR (4) SUB-MODES OF OPERATION:

1. COOLING
2. DEHUMIDIFICATION
3. REHEAT
4. HEATING

COOLING SUB-MODE

SALES AREA SETPOINTS: DB_{SP} - 74°F., DP_{SP} - 55°F., OA SETPOINTS: DB_{SP} - 75°F. (ADJ.) 65°F. MIN. M.O. FOR THE MAXIMUM AND MINIMUM CFM QUANTITIES. IF THERE IS A CALL FOR COOLING FROM THE ZONE THE CONTROLLER SHALL ENABLE THE SPECIFIED COOLING STAGES IN THE RA CIRCUIT TO LOWER THE ZONE DB_{SP}. THE CONTROLLER SHALL BE PROGRAMMED TO MEET A VARIABLE COIL # 1A LAT SETPOINT BASED ON THE ZONE'S DEW POINT.

OR CIRCUIT

COOL #1A DEHUMIDIFICATION COIL ACTIVATION SEQUENCE:
COOL #1 (DIGITAL SCROLL) COMPRESSOR SHALL ACTIVATE WHEN:

1. THE DP_{ZONE} RISES ABOVE DP_{SP}

COMP #1A SHALL CYCLE OFF WHEN:

1. THE DP_{ZONE} FALLS BELOW ZONE'S DP_{SP}
2. IF ANY FURNACE IS ENERGIZED ON

COOL #1, SECOND TANDUM COMPRESSOR (COMP #1B) SHALL ACTIVATE WHEN:

1. COOLING COIL #1A (DEHUMIDIFICATION COIL) LAT IS ABOVE COIL $1A_{SP}$ +1.0°F
2. THE DIGITAL SCROLL COMPRESSOR (COMP #1A) IS RUNNING AT MAXIMUM CAPACITY (0 (0 VOC) FOR THREE (3) MINUTES

COMP #1B SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #1A LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 VDC) FOR A PERIOD OF 3 MINUTES
3. THE DIGITAL SCROLL (PRECOOLING COIL) COMPRESSOR (COMP #2) IS ENABLED FOR THREE (3) MINUTES
4. ANY FURNACE IS ENERGIZED OFF
5. ANY FURNACE IS ENERGIZED ON

COOL #2 (PRE-COOLING COIL) ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2) SHALL ACTIVATE WHEN:

1. COMP #1A IS ENERGIZED AND IS AT MAXIMUM CAPACITY (5 (5 VDC) FOR A DURATION OF 3 MINUTES
2. COMP #1B IS ENERGIZED FOR THREE (3) MINUTES
3. COOLING COIL LAT IS ABOVE LAT_{SP} +2.0°F

COMP #2 SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #2 LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 V) FOR A DURATION OF 3 MINUTES
3. COMP #1A ENERGIZES OFF
4. ANY FURNACE IS ENERGIZED ON

RA CIRCUIT

RA COOLING COIL #2 ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2A & 2B) SHALL ACTIVATE WHEN:

1. DP_{ZONE} RISES AND REMAINS ABOVE ZONE'S DP_{SP} AFTER BEEN TRUE FOR 5 MINUTES THE CONTROLLER SHALL ACTIVATE COMP #2A. SHOULD COMP #2A'S DISCHARGE PRESSURE RISE ABOVE A PRESET LIMIT COMP #2B (ENERGIZES ON

COOL #2 COMPRESSORS (COMP #2A & 2B) SHALL ENERGIZE OFF WHEN:

1. AS THE HEAD PRESSURE DECREASES BELOW THE PRESET LIMIT COMP #2B SHALL DE-ENERGIZE OFF
2. COOLING COIL LAT DROPS BELOW LAT_{SP} -2.0°F
3. ANY FURNACE IS ENERGIZED ON

IF DURING THE DEHUMIDIFICATION MODE THE DP_{ZONE} FALLS BELOW ZONE'S DP_{SP} BY 3°F. THE CONTROLLER SHALL DE-ACTIVATE THE DEHUMIDIFICATION MODE.

SHOULD ANY COMPRESSOR CYCLE OFF THE ANTI-SHORT CYCLE TIME DELAYS PREVENTS REACTIVATION OF THE COMPRESSOR UNTIL A FIVE (5) MINUTE TIME DELAY EXPIRES BEGINNING AT THE TIME OF DEACTIVATION.

DEHUMIDIFICATION SUB MODE

IF THERE IS A CALL FOR DEHUMIDIFICATION (DP_{ZONE} > ZONE'S DP_{SP} OR DP_{SP} > OA DP_{SP}) THE CONTROLLER SHALL FIRST ENABLE (A CIRCUIT FOLLOWED BY THE RA CIRCUIT TO MAINTAIN THE ZONE DP_{SP}. THE OA CIRCUIT SHALL BE PROGRAMMED TO MEET A VARIABLE COOLING COIL #1A LAT_{SP} BASED ON ZONE'S DEW POINT (DP). THE CONTROLLER SHALL ADJUST THE LAT_{SP} TO RANGE BETWEEN 45°F AND 65°F.

SALES AREA SETPOINTS:

1. DP_{SP} - 55°F
2. DP_{SP} - 60°F

OA SETPOINTS:

DP_{SP} - 60°F.

REHEAT:

$RHC\,SP_{SP}$ 71°F

OA CIRCUIT

COOL #1A (DEHUMIDIFICATION COIL) ACTIVATION SEQUENCE:
COOL #1 (DIGITAL SCROLL) COMPRESSOR SHALL ACTIVATE WHEN:

1. THE DP_{ZONE} RISES ABOVE DP_{SP}

COMP #1A SHALL CYCLE OFF WHEN:

1. THE DP_{ZONE} FALLS BELOW ZONE'S DP_{SP}
2. IF ANY FURNACE IS ENERGIZED ON

COOL #1, SECOND TANDUM COMPRESSOR (COMP #1B) SHALL ACTIVATE WHEN:

1. COOLING COIL #1A (DEHUMIDIFICATION COIL) LAT IS ABOVE COIL $1A_{SP}$ +1.0°F
2. THE DIGITAL SCROLL COMPRESSOR (COMP #1A) IS RUNNING AT MAXIMUM CAPACITY (5 (5 VDC) FOR THREE (3) MINUTES

COMP #1B SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #1A LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 VDC) FOR A PERIOD OF 3 MINUTES
3. THE DIGITAL SCROLL (PRECOOLING COIL) COMPRESSOR (COMP #2) IS ENABLED FOR THREE (3) MINUTES
4. ANY FURNACE IS ENERGIZED OFF
5. ANY FURNACE IS ENERGIZED ON

COOL #2 (PRE-COOLING COIL) ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2) SHALL ACTIVATE WHEN:

1. COMP #1A IS ENERGIZED AND IS AT MAXIMUM CAPACITY (5 (5 VDC) FOR A DURATION OF 3 MINUTES
2. COMP #1B IS ENERGIZED FOR THREE (3) MINUTES
3. COOLING COIL LAT IS ABOVE LAT_{SP} +2.0°F

COMP #2 SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #2 LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 V) FOR A DURATION OF 3 MINUTES
3. COMP #1A ENERGIZES OFF
4. ANY FURNACE IS ENERGIZED ON

RA CIRCUIT

RA COOLING COIL #2 ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2A & 2B) SHALL ACTIVATE WHEN:

1. DP_{ZONE} RISES AND REMAINS ABOVE ZONE'S DP_{SP} AFTER BEEN TRUE FOR 5 MINUTES THE CONTROLLER SHALL ACTIVATE COMP #2A. SHOULD COMP #2A'S DISCHARGE PRESSURE RISE ABOVE A PRESET LIMIT COMP #2B (ENERGIZES ON

COOL #2 COMPRESSORS (COMP #2A & 2B) SHALL ENERGIZE OFF WHEN:

1. AS THE HEAD PRESSURE DECREASES BELOW THE PRESET LIMIT COMP #2B SHALL DE-ENERGIZE OFF
2. COOLING COIL LAT DROPS BELOW LAT_{SP} -2.0°F
3. ANY FURNACE IS ENERGIZED ON

IF DURING THE DEHUMIDIFICATION MODE THE DP_{ZONE} FALLS BELOW ZONE'S DP_{SP} BY 3°F. THE CONTROLLER SHALL DE-ACTIVATE THE DEHUMIDIFICATION MODE.

SHOULD ANY COMPRESSOR CYCLE OFF THE ANTI-SHORT CYCLE TIME DELAYS PREVENTS REACTIVATION OF THE COMPRESSOR UNTIL A FIVE (5) MINUTE TIME DELAY EXPIRES BEGINNING AT THE TIME OF DEACTIVATION.

REHEAT SUB-MODE

DURING THE REHEAT SUB-MODE THE CONTROL VALVE SHALL MODULATE OPEN TO MAINTAIN THE ZONE'S DB_{SP}. IF THE DB_{ZONE} FALLS BELOW ZONE'S DB_{SP} -0.5°F. THE REHEAT MODE IS ENABLED FOR THREE MINUTES (ADJUSTABLE) AND DB_{ZONE} < ZONE'S DB_{SP} -0.5°F. THE HW CONTROL VALVE SHALL MODULATE TO MAINTAIN THE ZONE'S DB_{SP}. IF THE DB_{ZONE} RISES ABOVE ZONE'S DB_{SP} +0.5°F. THE REHEAT MODE SHALL CYCLE OFF.

HEATING SUB-MODE

THE SUPPLY AIR'S (SA) SETPOINTS: DB_{SP} - 75°F. (ADJ.) 65°F. MIN. M.O. FOR THE MAXIMUM AND MINIMUM CFM QUANTITIES. IF THERE IS A CALL FOR HEATING FROM THE ZONE THE CONTROLLER SHALL MODULATE TO MAINTAIN THE ZONE'S DB_{SP}. THE CONTROLLER SHALL BE PROGRAMMED TO MEET A VARIABLE COIL # 1A LAT SETPOINT BASED ON THE ZONE'S DEW POINT.

OR CIRCUIT

COOL #1A DEHUMIDIFICATION COIL ACTIVATION SEQUENCE:
COOL #1 (DIGITAL SCROLL) COMPRESSOR SHALL ACTIVATE WHEN:

1. THE DP_{ZONE} RISES ABOVE DP_{SP}

COMP #1A SHALL CYCLE OFF WHEN:

1. THE DP_{ZONE} FALLS BELOW ZONE'S DP_{SP}
2. IF ANY FURNACE IS ENERGIZED ON

COOL #1, SECOND TANDUM COMPRESSOR (COMP #1B) SHALL ACTIVATE WHEN:

1. COOLING COIL #1A (DEHUMIDIFICATION COIL) LAT IS ABOVE COIL $1A_{SP}$ +1.0°F
2. THE DIGITAL SCROLL COMPRESSOR (COMP #1A) IS RUNNING AT MAXIMUM CAPACITY (5 (5 VDC) FOR THREE (3) MINUTES

COMP #1B SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #1A LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 VDC) FOR A PERIOD OF 3 MINUTES
3. THE DIGITAL SCROLL (PRECOOLING COIL) COMPRESSOR (COMP #2) IS ENABLED FOR THREE (3) MINUTES
4. ANY FURNACE IS ENERGIZED OFF
5. ANY FURNACE IS ENERGIZED ON

COOL #2 (PRE-COOLING COIL) ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2) SHALL ACTIVATE WHEN:

1. COMP #1A IS ENERGIZED AND IS AT MAXIMUM CAPACITY (5 (5 VDC) FOR A DURATION OF 3 MINUTES
2. COMP #1B IS ENERGIZED FOR THREE (3) MINUTES
3. COOLING COIL LAT IS ABOVE LAT_{SP} +2.0°F

COMP #2 SHALL ENERGIZE OFF WHEN:

1. COOLING COIL #2 LAT DROPS BELOW LAT_{SP} -2.0°F
2. COMP #1A IS AT MINIMUM CAPACITY (2 (2 VDC)
3. COMP #1A ENERGIZES OFF
4. ANY FURNACE IS ENERGIZED ON

RA CIRCUIT

RA COOLING COIL #2 ACTIVATION SEQUENCE:
COOL #2, COMPRESSOR (COMP #2A & 2B) SHALL ACTIVATE WHEN:

1. DP_{ZONE} RISES AND REMAINS ABOVE ZONE'S DP_{SP} AFTER BEEN TRUE FOR 5 MINUTES THE CONTROLLER SHALL ACTIVATE COMP #2A. SHOULD COMP #2A'S DISCHARGE PRESSURE RISE ABOVE A PRESET LIMIT COMP #2B (ENERGIZES ON

COOL #2 COMPRESSORS (COMP #2A & 2B) SHALL ENERGIZE OFF WHEN:

1. AS THE HEAD PRESSURE DECREASES BELOW THE PRESET LIMIT COMP #2B SHALL DE-ENERGIZE OFF
2. COOLING COIL LAT DROPS BELOW LAT_{SP} -2.0°F
3. ANY FURNACE IS ENERGIZED ON

SHOULD ANY COMPRESSOR CYCLE OFF THE ANTI-SHORT CYCLE TIME DELAY PREVENTS REACTIVATION OF THE COMPRESSOR UNTIL A FIVE (5) MINUTE TIME DELAY EXPIRES BEGINNING AT THE TIME OF DEACTIVATION.

UNOCCUPIED MODE

THE UNOCCUPIED MODE SHALL CORRESPOND TO THE STORE'S CLOSING PERIOD. AT THE START OF THE UNOCCUPIED PERIOD THE CONTROLLER SHALL TAKE THE FOLLOWING ACTIONS:

1. A FAN'S VFD SHALL RAMP DOWN
2. A FAN'S VFD SHALL RAMP TO MINIMUM CFM (45,000 CFM)
3. RA BYPASS DAMPER SHALL OPEN

THE NIGHT SET BACK DAMPER CONTROL SHALL OPEN THE RA BYPASS DAMPER TO REDIRECT A PORTION OF THE RA STREAM TO THE OA CIRCUIT. THE CONDITIONED RA SHALL MIX WITH UNTREATED RA BEFORE IT IS SUPPLIED TO THE ZONE.

THE UNOCCUPIED MODE HAS FOUR (4) SUB-MODES OF OPERATION

1. COOLING
2. DEHUMIDIFICATION
3. REHEAT
4. HEATING

THE UNOCCUPIED SUB MODES ARE SEQUENCED IN THE SAME MANNER AS THE OCCUPIED MODE. SEE THE OCCUPIED MODE FOR SEQUENCING.

OVERRIDE MODE

IF DURING THE UNOCCUPIED MODE THE MELINK SIGNALS THE CPC CONTROL BOARD TO OPERATE IN THE OCCUPIED MODE AC-1 SHALL REVERT TO THE OCCUPIED MODE FOR A SPECIFIED TIME PERIOD (ADJUSTABLE).

ALARMS

SMOKE DETECTORS SHALL MONITOR SA AND RA AIR FLOW'S FOR FIRE INDUCED SMOKE. IN EVENT OF A SMOKE EVENT ANY SMOKE DUCT DETECTOR SHALL INITIATE A SIGNAL WHICH ALERTS THE FIRE ALARM SYSTEM. SIMULTANEOUSLY, THE SMOKE DUCT DETECTOR SHALL SECURE THE 24V CONTROL POWER TO THE REVERSE ACTING FIRE OVER RELAY. IN THE UNIT CAUSING THE RELAY TO OPEN AND DISABLE THE SA FAN WHICH IN TURN SECURES POWER TO THE ROOFTOP UNIT. THE RELAY SHALL REMAIN IN THE DISABLED MODE UNTIL THE FIRE ALARM SYSTEM RESETS THE SMOKE DUCT DETECTOR. THE SMOKE DUCT DETECTOR WILL RESTORE 24V CONTROL POWER TO THE FIRE POWER RELAY WHICH IN TURN ENABLES THE SA FAN CIRCUIT.

ANALOG OUTPUTS

1. COMP #1 (DIGITAL SCROLL COMPRESSOR) _____ ANALOG OUTPUT 1
2. SA HEATER (GAS CONTROL VALVE / ELECTRICAL COIL _____ ANALOG OUTPUT 2
3. SA FAN VFD _____ ANALOG OUTPUT 3
4. HOT WATER/REHEAT VALVE _____ ANALOG OUTPUT 4
5. OA DAMPER ACTUATOR _____ ANALOG OUTPUT 5

ANALOG INPUTS

1. ZONE DB TEMPERATURE SENSOR _____ ANALOG INPUT 1
2. ZONE DP TEMPERATURE SENSOR _____ ANALOG INPUT 2
3. SA DB TEMPERATURE SENSOR _____ ANALOG INPUT 3
4. RA DB TEMPERATURE SENSOR _____ ANALOG INPUT 4
5. COOL #1 DB LAT SENSOR _____ ANALOG INPUT 5
6. COOL #2 DB LAT SENSOR _____ ANALOG INPUT 6
7. COOL #2 DB LAT