



- KEY NOTES:
- 1 REMOVE EXISTING 2" CW AND 1" HW PIPE PASSING OVER NEW ELECTRICAL PANEL. ROUTE NEW 2" CW AND 1" HW AND RECONNECT TO EXISTING, REMOVE EXISTING CW AND HW BRANCH LINES SERVING OLD FIXTURES.
 - 2 CONNECT NEW 3/4" HW PIPING TO EXISTING HW PIPING. CONTRACTOR SHALL FIELD VERIFY EXACT SIZE, LOCATION AND ELEVATION OF EXISTING PRIOR TO INSTALLATION.
 - 3 CONNECT NEW 3/4" FW PIPING TO EXISTING FW PIPING. CONTRACTOR SHALL FIELD VERIFY EXACT SIZE, LOCATION AND ELEVATION OF EXISTING PRIOR TO INSTALLATION.
 - 4 CONNECT NEW 1/2" CW PIPE TO EXISTING HOSE BIBB.
 - 5 ROUTE 3/4" CW TO CHILL KING. ROUTE 3/4" CW AND HW TO SINK. PROVIDE AND INSTALL 3/4" WATTS LF-919-QTS AT ELEVATION ABOVE SINKS. ROUTE DRAIN OF BACKFLOW DEVICE TO FLOOR SINK BELOW PREP SINK. COORDINATE WITH MANUFACTURERS CUT SHEETS FOR ROUGH-IN REQUIREMENTS FOR CHILL KING PRIOR TO INSTALLATION.



STORE #6679

6808 SIEGEN LANE
BATON ROUGE, LA 70809

PROJ. NO.: 1722
DATE: 01/22/2018

SHEET TITLE:
FLOOR PLAN
- PLUMBING

DRAWING SHEET IS FULL SIZE AT 22" x 34"
REDUCED 11" x 17" SHEET IS HALF SIZE

SHEET NO.:

P1.02

Order Plans @

1 FLOOR PLAN - WATER
1/4" = 1' - 0"