





**CURB INLET FILTER "PIGS IN BLANKET" Sd2-P**  
SCALE: N.T.S.

- NOTES:**
1. INSTALL FILTER AFTER ANY ASPHALT PAVEMENT INSTALLATION.
  2. WRAP 8" CONCRETE BLOCKS IN FILTER FABRIC AND SPAN ACROSS CATCH BASIN INLET.
  3. FACE OPENINGS IN BLOCKS OUTWARD.
  4. LEAVE A GAP OF APPROXIMATELY 4 INCHES BETWEEN THE CURB AND THE FILTERS TO ALLOW FOR OVERFLOW TO PREVENT HAZARDOUS PONDING.
  5. INSTALL OUTLET PROTECTION BELOW STORM DRAIN OUTLETS.



**FABRIC AND SUPPORTING FRAME FOR INLET PROTECTION Sd2-P**  
SCALE: N.T.S.


- NOTES:**
1. DESIGN IS FOR SLOPES NO GREATER THAN 5% (NOT DESIGNED FOR CONCENTRATED FLOWS).
  2. THE STEEL POSTS SUPPORTING THE SILT FENCE MATERIAL SHOULD BE SPACED EVENLY AROUND THE PERIMETER OF THE INLET (MAXIMUM OF 3' APART).
  3. THE STEEL POSTS SHOULD BE SECURELY DRIVEN AT LEAST 18" DEEP.
  4. THE FABRIC SHOULD BE ENTRENCHED AT LEAST 12" AND THEN BACKFILLED WITH CRUSHED STONE OR COMPACTED SOIL.




**LARGE TREE PLANTING (OVER 6")**  
SCALE: N.T.S.

- NOTES:**
1. IF PLASTIC BURLAP OR WIRE BASKETS ARE ON TREES, REMOVE THEM ENTIRELY BEFORE PLACING TREE IN THE PLANT PIT.
  2. REMOVE ALL CORD, WIRE TIES AND PLASTIC TUBING OR OTHER BINDING MATERIALS BEFORE PLACING TREE IN THE PLANT PIT.
  3. PLANTING SOIL MIX CONSISTS OF 2 PARTS GOOD QUALITY TOPSOIL TO 1 PART SOIL AMENDMENT. SOIL AMENDMENT IS EQUAL PARTS SPAGHNUM PEAT MOSS, STERILE MANURE AND MYCORRHIZAL TREE SAVER TRANSPLANT. NO FERTILIZER SHOULD BE ADDED TO THE PLANTING SOIL MIX AT THE TIME OF PLANTING.


**Excavated Inlet Sediment Trap.**  
An excavation may be created around the inlet sediment trap to provide additional sediment storage. The trap shall be sized to provide a minimum storage capacity calculated at the rate of 67 cubic yards per acre of drainage area. A minimum depth of 1.5 feet for sediment storage should be provided. Side slopes shall not be steeper than 2:1. Sediment traps may be constructed on natural ground surface, on an excavated surface, or on machine compacted fill, provided they have a non-erodible outlet.



**EXCAVATED INLET SEDIMENT TRAP Sd2-F**  
SCALE: N.T.S.




**INLET SEDIMENT TRAP Sd2-F**  
SCALE: N.T.S.



- SHRUB PLANTING NOTES:**
1. DIG PLANTING HOLE AT LEAST 2X THE WIDTH OF THE ROOT BALL OR CONTAINER.
  2. SCARIFY SUBGRADE AND SIDES OF PLANTING HOLE WHEN PLANTING IN CLAY SOIL.
  3. SET THE TOP OF THE ROOT BALL LEVEL WITH THE SOIL SURFACE, OR 1-2" ABOVE IF THE SOIL IS PRONE TO SETTLING.
  4. IF CONTAINER GROWN PLANT, GENTLY SLIDE PLANT OUT OF CONTAINER. DISTURB THE ROOTS.
  5. IF B&B PLANT, REMOVE BURLAP FROM AT LEAST THE TOP 12 INCHES OF THE ROOT BALL, WITHOUT DISTURBING THE ROOT BALL. REMOVE ALL CORD FROM THE TRUNK. REMOVE BURLAP AND WIRE BASKET (IF PRESENT) FROM THE ROOT BALL.
  6. BACK FILL THE PLANTING HOLE WITH EXCAVATED NATIVE SOIL, BROKEN UP OR TILLED. WATER TO REMOVE AIR POCKETS. DO NOT ADD AMENDMENTS.
  7. PLACE PINE STRAW OR BARK MULCH ON THE SURFACE TO A (SETTLED) DEPTH OF 1 TO 3 INCHES.

**TYPICAL SHRUB PLANTING**  
SCALE: N.T.S.



GEORGIA STATE BOARD OF PROFESSIONAL ENGINEERS



GEORGIA STATE BOARD OF PROFESSIONAL ENGINEERS

**T. R. Long Engineering, P.C.**  
SAVANNAH  
306 Commercial Drive  
Savannah, Georgia 31406  
Office (912) 335-1046



www.trlongeng.com

HINESVILLE  
114 North Commerce St.  
Hinesville, Georgia 31313  
Office (912) 368-5664

**SPECIFIC DEVELOPMENT  
PLAN FOR BURGER KING  
NAHANTA, GEORGIA**

TAX PARCEL NUMBER: XXXX NAHANTA, BRANTLEY COUNTY, GA

SHEET NAME:  
SWPPP  
DETAILS

REVISIONS:

1.
2.
3.
4.
5.
6.
7.
8.
9.
10.

INITIAL DATE: 4/01/2019  
DRAWN BY: BDP  
CHECKED BY: TRL  
PROJECT #: 2018-147

SHEET NUMBER:

EC-06