



Order Plans @ [www.waveonline.com](http://www.waveonline.com)

**ENLARGED PUBLIC AREA POWER PLAN**  
SCALE: 1/4" = 1'-0"

- KEYED NOTES THIS SHEET**
- COORDINATE WITH SPECIFIC OWNER EQUIPMENT PRIOR TO ANY ROUGH-IN WORK. WIRING CONDUCTORS AND DISCONNECT SWITCHES MAY VARY FROM INDICATED HERE-IN. PROVIDE 60°F/1P/3P FOR WASHER AND 30°F/1P/3P FOR DRYERS UNLESS DETERMINED BY EQUIPMENT COORDINATION.
  - COORDINATE WITH ECOLAB EQUIPMENT. RELOCATE TO VICINITY OF EQUIPMENT.
  - PROVIDE CONNECTION TO MOTORIZED DAMPER AS REQUIRED FOR OPERATION. COORDINATE AND INTERLOCK WITH DRYER VIA INPUT ON CONTROL BOARD OF EACH DRYER. COORDINATE LV CONTROL WIRING WITH EQUIPMENT VENDOR.
  - PROVIDE CONNECTION TO LAUNDRY CHUTE AS REQUIRED FOR OPERATION. PROVIDE SMOKE DETECTORS AS REQUIRED PER CHUTE SUBMITTAL AT TOP, BOTTOM & INTERMEDIATE STOP LOCATIONS.
  - COORDINATE MOUNTING HEIGHT WITH OWNER/ARCHITECT PRIOR TO ANY ROUGH-IN WORK.
  - COORDINATE WITH MECHANICAL CONTRACTOR TO PROVIDE FIRE ALARM AND LINE VOLTAGE CONNECTIONS FOR ALL FIRE/SMOKE DAMPERS. FIRE ALARM ACTIVATION TO CLOSE ALL ELECTRONICALLY ACTUATED FIRE/SMOKE DAMPERS. EC TO PROVIDE RIB DAMPERS.
  - RELAY FOR EACH: PROVIDE SWITCHED CONNECTION FOR MOTORIZED DOORS. COORDINATE WITH INSTALLER PRIOR TO ROUGH-IN WORK.
  - PROVIDE 3/4" CONDUIT TO INTERCOM STATION IN VESTIBULE. PROVIDE 120V CONNECTION AS REQUIRED FOR OPERATION.
  - PROVIDE 3/4" CONDUIT FOR INTERLOCK CONTROLS FOR AUTOMATIC DOOR AS REQUIRED PER ARCHITECT'S HARDWARE SCHEDULE. PROVIDE 120V CONNECTION AS REQUIRED FOR OPERATION.
  - VERIFY LOCATION OF ALL POWER THIS ROOM WITH HILTON PROJECT MANAGER PRIOR TO ANY ROUGH-IN WORK.
  - COORDINATE LOCATION OF ALL WIRING DEVICES WITH PROPERTIES EVENT COORDINATOR PRIOR TO ROUGH-IN WORK FOR FEED BACK ON ELECTRICAL DEVICE PLACEMENT.
  - COORDINATE PLACEMENT OF ALL WIRING DEVICES, TV OUTLETS, FLOOR BOXES, ETC WITH VENDOR(S), PROPERTY MANAGER, & HILTON PROJECT MANAGER PRIOR TO ANY ROUGH-IN WORK.
  - PROVIDE CONNECTION TO ELECTRONIC HAND DRYERS AS REQUIRED PER ARCHITECTURAL SPECIFICATIONS.
  - COORDINATE WITH ARCHITECTURAL ELEVATIONS AND BACKING PRIOR TO ANY ROUGH-IN WORK.
  - COORDINATE WITH DRY COMPRESSOR LOCATION. COORDINATE WITH FIRE PROTECTION CONTRACTOR.
  - COORDINATE WITH DOMESTIC BOOSTER PUMP AND PLUMBING CONTRACTOR AS REQUIRED AT SITE. ALLOCATED 80A/3P CIRCUIT AND FUSED DISCONNECT.