




• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.




• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.




• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.



• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.



• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.



• SEAL ALL DUPONT™ TYVEK® SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 • FASTEN DUPONT™ TYVEK® WITH APPROVED FASTENERS AND SPACING.  
 • INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 • LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.  
 • EXTERIOR INSULATION MAY BE APPLIED IN FRONT OR BEHIND DUPONT™ TYVEK® LAYER.

NOTE:  
 TYVEK ENVELOPE AND FLASHING DETAILS ARE GENERIC. ACTUAL CONDITIONS MAY VARY FOR THIS PROJECT. GENERAL CONTRACTOR SHALL BE RESPONSIBLE FOR COORDINATION AND FIELD ADJUST AS REQUIRED.

Order Plans @ WWW.WWJline.com

WWW.WWJline.com

REVISIONS	
NO.	DESCRIPTION

RENEWED MEDICAL BUILDING  
 CORE & SHELL ONLY

SOUTH FULTON, GEORGIA  
 PROJECT #19-2983



PERMIT SET  
 MARCH 27, 2020  
 RELEASE DATE

EXTERIOR  
 DETAILS-  
 FLASHING

DRAWING TITLE

© COPYRIGHT 2020 JEFFERSON BROWNE GRESHAM ARCHITECTS, INC. THIS DOCUMENT IS AN INSTRUMENT OF SERVICE. IT REMAINS THE PROPERTY OF JEFFERSON BROWNE GRESHAM ARCHITECTS AND NO PART THEREOF MAY BE REPRODUCED IN ANY FORM WITHOUT WRITTEN PERMISSION FROM JEFFERSON BROWNE GRESHAM ARCHITECTS.