

**CASE INSTALLATION**

\*\*\*NOTE\*\*\*  
THIS DOCUMENT IS INTENDED TO DESCRIBE IMPORTANT ELEMENTS OF THIS PROJECT AND TO DEFINE THE RESPONSIBLE PARTIES FOR THIS WORK STREAM. IT IS NOT MEANT TO BE AN EXHAUSTIVE SOURCE OF INFORMATION OR A COMPLETE SCOPE OF WORK. IT SHOULD BE READ AND USED IN CONJUNCTION WITH ADDITIONAL, DETAILED INFORMATION IN THE WALMART REALTY ONE BEST WAY STANDARDS LIBRARY, AND IN PUBLICATIONS AVAILABLE FROM THE MANUFACTURER.

#	SCOPE OF WORK	RESPONSIBLE PARTY			
		REPLACEMENTS		NEW EQUIPMENT	
		REMODEL	CAPEX	REMODEL	CAPEX
1	FURNISH THE NEW / REPLACEMENT CASES.	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT
2	FURNISH AND INSTALL ALL REFRIGERANT AND DRAIN PIPING, AND ALL FIELD INSTALLED REFRIGERATION VALVES NECESSARY TO COMPLETE THE WORK.	RC	RC	RC	RC
3	FURNISH ALL CONTROLS CABLING AS NECESSARY TO COMPLETE THE WORK. (24 VOLTS OR LESS)	EMS	EMS	EMS	EMS
4	PROVIDE TYPEWRITTEN SCHEDULES FOR ALL AFFECTED ELECTRICAL PANELS/DRAYS.	GC	RC	GC	RC
5	INSTALL AND TERMINATE FURNISHED CONTROLS WIRING (24 VOLTS OR LESS) AS DETAILED ON THE PRINTS.	RC	RC	RC	RC
6	PROVIDE ELECTRICAL POWER CABLING FROM POWER SOURCE TO THE FIRST CASE IN THE CIRCUIT.	GC	RC	GC	RC
7	PROVIDE ALL "SLAVE" WIRING FROM FIRST CASE TO REMAINING CASES ON THE CIRCUIT.	RC	RC	RC	RC
8	PREFABRICATE AS MUCH OF THE NEW PIPE WORK AND ELECTRICAL CONDUIT AS POSSIBLE AND MOUNT ANY NEW DEVICES IN ORDER TO REDUCE THE AMOUNT OF "DOWN TIME".	RC	RC	RC	RC
9	COORDINATE THE INSTALLATION TIME WITH STORE...	GC	RC	GC	RC
10	OBTAIN HOT WORK PERMITS AS REQUIRED.	GC	RC	GC	RC
11	NOTIFY THE EMS VENDOR 24 HRS. IN ADVANCE OF THE WORK - TELL THEM WHAT CASES ARE BEING INSTALLED AND WHAT SYSTEMS WILL BE IMPACTED.	RC	RC	RC	RC
12	NOTIFY THE WMT BUILDING CONTROLS TEAM AND ADVISE THEM WHICH SYSTEMS AND WHICH CASES WILL BE IMPACTED BY THE WORK.	RC	RC	N/A	N/A
13	REMOVE ALL OF REFRIGERATED PRODUCTS FROM THE CASES THAT ARE BEING REPLACED.	WMT	WMT	N/A	N/A
14	REMOVE ALL OF THE ASSET PROTECTION (BUMP GUARDS) FROM AROUND THE CASES.	GC	RC	N/A	N/A
15	DECOMMISSION AND REMOVE THE OLD CASES. IN TEXAS, ALL DECOMMISSIONED CASES WILL BE REMOVED FROM THE STORE BY QUICK REFRIGERATION. COORDINATE REMOVAL AND DISPOSAL WITH WMT CONSTRUCTION MANAGER. WHEN REPLACING PRODUCE CASES, REMOVE WATER SUPPLY FROM MISTING SYSTEM. WHEN REPLACING DELI SERVE OVER CASES, COORDINATE THE REMOVAL OF THE DATA CABLING FOR THE DELI SCALES.	RC	RC	N/A	N/A
16	CLEAN THE FLOOR UNDER THE CASES AND JET THE DRAINS. WHEN REPLACING MULTIDECK AND /OR GLASS DOOR CASES, AND REINSULATE EXISTING PIPEWORK, RE-INSULATE THE REFRIGERATION PIPING BEHIND THE CASES. THIS APPLIES TO ALL PIPING THAT IS ACCESSIBLE WITHOUT DISTURBING EXISTING CASES. INSIDE PITS / TUNNELS OR IN A CHASE THAT IS NOT BEING OTHERWISE DISTURBED.	RC	RC	N/A	N/A
17	SET THE NEW CASES IN THE POSITION DICTATED BY THE CONSTRUCTION PRINTS ON THE EXISTING WALK-IN BOX AND LEVEL AND SHIMMED PER THE MANUFACTURER'S GUIDANCE. SEAL ALL CASES WITH BUTYL SEALANT, ALIGN GLASS DOORS PLUMB AND LEVEL TO PREVENT "SAW TOOTHING" OF THE DOORS.	RC	RC	N/A	N/A
18	CONNECT THE NEW CASES (MECHANICAL, ELECTRICAL PLUMBING AND CONTROLS) AS DETAILED ON THE PRINTS.	RC	RC	RC	RC
19	EVAUATE AND PRESSURE TEST THE NEW CASES AND ANY PIPING MODIFIED OR DISTURBED DURING THE WORK.	RC	RC	RC	RC
20	SWITCH ON AND COMMISSION THE NEW CASES, VALVES AND CONTROLS AS REQUIRED. CHECK AND ADJUST MECHANICAL TVX SUPERHEATS TO OEM RECOMMENDATIONS AND EPR.	RC	RC	RC	RC
21	INSTALL FURNISHED LIDS TO REFRIGERATED BUNKERS.	RC	RC	RC	RC
22	FURNISH CONTROLS SUPPORT TO THE INSTALLING CONTRACTOR.	OEM	OEM	OEM	OEM
23	WHEN REPLACING PRODUCE CASES, INSTALL NEW MISTING SYSTEM TO CASES AND CONNECT TO DEDICATED WATER SUPPLY.	RC	RC	RC	RC
24	WHEN REPLACING DELI SERVE OVER CASES, COORDINATE THE INSTALLATION OF THE DATA CABLING FOR THE DELI SCALES.	WMT	RC/WMT	WMT	RC/WMT
25	NOTIFY WMT BUILDING CONTROLS THAT THE NEW CASES ARE RUNNING AND ONLINE.	RC	RC	RC	RC
26	CARRY OUT A THOROUGH LEAK TEST ON ALL WELDED AND MECHANICAL JOINTS INSTALLED OR DISTURBED DURING THE PROJECT.	RC	RC	RC	RC
27	HANDOVER THE NEW CASES TO THE STORE (CASES MUST BE CLEAN, AT OPERATIONAL TEMPERATURE AND FULLY FUNCTIONAL WITH ALL PANS AND SHELVS IN PLACE.)	RC	RC	RC	RC
28	FILL THE NEW CASE WITH PRODUCT.	WMT	WMT	WMT	WMT
29	REPLACE MISSING OR DAMAGED FLOOR TILES OR REPAIR VISIBLE, DAMAGED CONCRETE FLOOR AROUND THE NEW CASES. (AS NEEDED)	GC (OR WMT PREFERRED FLOORING INSTALLER)	RC	N/A	N/A
30	INSTALL NEW CIRCUIT LABELS TO THE NEW CASES AS...	RC	RC	RC	RC
31	REPLACE THE SHOP FLOOR DRAWINGS AND INSTALL REPLACEMENT LEGENDS.	RC	RC	RC	RC
32	REINSTALL ANY PREVIOUSLY REMOVED (UNDAMAGED) ASSET PROTECTION (BUMP GUARDS). INSTALL NEW OWNER FURNISHED PROTECTION EQUIPMENT AS NEEDED.	RC	RC	RC	RC
33	AFTER ALL CHANGES HAVE BEEN MADE TO A RACK, REMOVE ANY COMPRESSOR SUCTION FILTERS / SOCKS AND REPLACE THE RACK LIQUID LINE FILTERS. LEAVE THE OLD FILTERS...	RC	RC	RC	RC
34	SUBMIT REQUIRED VERISAE AND OTHER REGULATORY FORMS AS REQUIRED BY THE END OF COMMISSIONING WEEK. COMPLETED VERISAE FORMS ARE TO BE EMAILED TO MCEOUP@WAL-MART.COM.	RC	RC	RC	RC
35	REMOVE ALL OF THE OLD CASES AND CLEAR SITE OF ALL TOOLS, UNUSED INSTALLATION MATERIALS AND TRASH.	GC	RC	GC	RC

**ABBREVIATION LEGEND**

ABBREVIATION	DESCRIPTION
RC	REFRIGERATION CONTRACTOR AND SUB-CONTRACTORS
GC	GENERAL CONTRACTOR AND SUB-CONTRACTORS
EMS	EMS VENDOR
OEM	ORIGINAL RACK EQUIPMENT MANUFACTURER, ORIGINAL MANUFACTURER, AHU MANUFACTURER, RTU MANUFACTURER
PS	WALK-IN BOX PANEL SUPPLIER
WMT	WALMART
AES	SUPPLIER OF AHU ADAPTER CURBS, RTU ADAPTER CURBS AND WALMARTS EQUIPMENT SALVAGE PARTNER
WTC	WATER TREATMENT CONTRACTOR
MC	MECHANICAL CONTRACTOR AND SUB-CONTRACTORS

**WALK-IN BOX PROJECTS**

\*\*\*NOTE\*\*\*  
THIS DOCUMENT IS INTENDED TO DESCRIBE IMPORTANT ELEMENTS OF THIS PROJECT AND TO DEFINE THE RESPONSIBLE PARTIES FOR THIS WORK STREAM. IT IS NOT MEANT TO BE AN EXHAUSTIVE SOURCE OF INFORMATION OR A COMPLETE SCOPE OF WORK. IT SHOULD BE READ AND USED IN CONJUNCTION WITH ADDITIONAL, DETAILED INFORMATION IN THE WALMART REALTY ONE BEST WAY STANDARDS LIBRARY, AND IN PUBLICATIONS AVAILABLE FROM THE MANUFACTURER.

#	SCOPE OF WORK	RESPONSIBLE PARTY							
		BATTEN AND SEAL		RELINE		REPLACE EVAPORATOR/BOX			
		REMODEL	CAPEX	REMODEL	CAPEX	REMODEL	CAPEX	REMODEL	CAPEX
1	DEPENDING ON THE SCOPE OF WORK, FURNISH BATTEN AND SEAL, RELINE OR WALK-IN PANELS MATERIALS.	PS/WMT	PS/WMT	PS/WMT	PS/WMT	PS/WMT	PS/WMT	PS/WMT	PS/WMT
2	DEPENDING ON THE SCOPE OF WORK, FURNISH NEW EVAPORATORS AS REQUIRED.	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT	OEM/WMT
3	DEPENDING ON THE SCOPE OF WORK, FURNISH NEW EVAPORATOR CONTROL PANELS	EMS/WMT	EMS/WMT	EMS/WMT	EMS/WMT	EMS/WMT	EMS/WMT	EMS/WMT	EMS/WMT
4	FURNISH AND INSTALL ALL (REFRIGERANT AND DRAIN) PIPING, AND ALL FIELD INSTALLED REFRIGERATION VALVES NECESSARY TO COMPLETE THE WORK.	RC	RC	RC	RC	RC	RC	RC	RC
5	FURNISH ALL CONTROLS CABLING AS NECESSARY TO COMPLETE THE WORK. (24 VOLTS OR LESS)	EMS	EMS	EMS	EMS	EMS	EMS	EMS	EMS
6	INSTALL AND TERMINATE CONTROLS WIRING (24 VOLTS OR LESS) AS DETAILED ON THE PRINTS.	RC	RC	RC	RC	RC	RC	RC	RC
7	FURNISH AND INSTALL ALL ELECTRICAL POWER CABLING FROM POWER SOURCE TO THE EVAPORATOR CONTROL PANEL IF NECESSARY.	GC	RC	GC	RC	GC	RC	GC	RC
8	TERMINATE POWER CABLES TO THE EVAPORATOR CONTROL PANEL.	RC	RC	RC	RC	RC	RC	RC	RC
9	PREFABRICATE AS MUCH OF THE NEW PIPE WORK AND ELECTRICAL CONDUIT AS POSSIBLE AND MOUNT ANY NEW DEVICES IN ORDER TO REDUCE THE AMOUNT OF "DOWN TIME" NEEDED TO COMPLETE THE INSTALLATION.	RC	RC	RC	RC	RC	RC	RC	RC
10	COORDINATE THE INSTALLATION TIME WITH STORE MANAGEMENT.	GC	RC	GC	RC	GC	RC	GC	RC
11	OBTAIN HOW WORK PERMITS AS REQUIRED.	GC	RC	GC	RC	GC	RC	GC	RC
12	FURNISH TEMPORARY REFRIGERATED STORAGE AS NECESSARY.	WMT	WMT	WMT	WMT	WMT	WMT	WMT	WMT
13	NOTIFY THE EMS VENDOR 24 HRS. IN ADVANCE OF THE WORK - TELL THEM WHICH WALK-IN BOXES ARE BEING IMPACTED.	RC	RC	RC	RC	RC	RC	RC	RC
14	NOTIFY THE WMT BUILDING CONTROLS TEAM AND ADVISE THEM WHICH SYSTEM AND WHICH WALK-IN BOX WILL BE IMPACTED BY THE WORK.	RC	RC	RC	RC	RC	RC	RC	RC
15	REMOVE ALL OF REFRIGERATED PRODUCTS FROM THE WALK-IN BOX THAT IS BEING IMPACTED.	WMT	WMT	WMT	WMT	WMT	WMT	WMT	WMT
16	SHUT DOWN THE WALK-IN BOX THAT IS BEING IMPACTED. NOTE: ALLOW LOW TEMP ROOMS TO "DEFROST" FOR A PERIOD OF 72 HOURS TO ENSURE ALL ICE HAS MELTED FROM THE PANELS. ICE MELT NEEDS TO BE KEPT CLEAR THROUGHOUT THIS TIME TO ENSURE THAT WATER IS NOT REABSORBED BY THE PANELS.	RC	RC	RC	RC	RC	RC	RC	RC
17	REMOVE ALL OF THE RACKING FROM INSIDE THE WALK-IN BOX THAT IS BEING IMPACTED.	WMT	RC	WMT	RC	WMT	RC	WMT	RC
18	REMOVE ANY PROTECTION DEVICES / STRUCTURES THAT WILL IMPEDE THE COMPLETION OF THE WORK.	GC	RC	GC	RC	GC	RC	GC	RC
19	REMOVE ALL UTILITIES (CONDENSATE PIPING, CONDUITS, J-BOX, LIGHTING, FIRE SUPPRESSION ETC.) IN ORDER TO ALLOW FOR THE WORK TO BE CARRIED OUT.	GC	RC	GC	RC	GC	RC	GC	RC
20	REMOVE THE APX REPEATER FROM THE WALK-IN BOX THAT IS BEING IMPACTED. STORE THE DEVICE FOR REUSE FOLLOWING COMPLETION OF THE WALK-IN WORK.	GC	RC	GC	RC	GC	RC	GC	RC
21	REMOVE THE REFRIGERATION EVAPORATOR(S) FROM THE AFFECTED WALK-IN BOX AS NEEDED.	GC	RC	GC	RC	GC	RC	GC	RC
22	FILL ANY GAPS IN THE PANEL JOINTS WITH SEALANT OR EXPANDABLE FOAM PRIOR TO TAPING THE JOINT.	PS	PS	PS	PS	PS	N/A	N/A	N/A
23	CLEAN WALLS AND REPAIR ANY FAULTY PANELS IN PREPARATION FOR BATTEN / SEALING OF THE WALL JOINTS WITHIN THE BOX THAT IS BEING REPAIRED. CARRY OUT THE BATTEN AND SEAL PROCESS.	PS	PS	N/A	N/A	N/A	N/A	N/A	N/A
24	CLEAN WALLS AND REPAIR ANY FAULTY PANELS IN PREPARATION FOR RELINING THE BOX THAT IS BEING REPAIRED. RE-LINE THE WALK-IN BOX AND BATTEN / SEAL THE CEILING JOINTS WITHIN THE BOX.	N/A	N/A	PS	PS	N/A	N/A	N/A	N/A
25	DISCONNECT ANY FALL PROTECTION NETTING FROM THE TOP OF THE WALK-IN BOX, LEAVING IT ATTACHED TO THE ROOF MEMBERS, STOW IT OUT OF THE WAY FOR FUTURE RE-USE. DEMOLISH AND REMOVE THE EXISTING WALK-IN BOX PANELS.	N/A	N/A	N/A	N/A	PS	N/A	N/A	N/A
26	PROVIDE SUPPORT FOR ANY ITEMS THAT MAY BE MOUNTED TO THE EXTERIOR OF THE WALK-IN BOX THAT WILL REMAIN IN SERVICE DURING THE BOX REPLACEMENT. (FOR EXAMPLE PANEL BOARDS, EMS BACKBOARDS ETC.)	N/A	N/A	N/A	N/A	N/A	PS	PS	PS
27	REPLACE THE WOODEN THERMAL BREAKS AS NECESSARY.	N/A	N/A	N/A	N/A	N/A	GC	RC	GC
28	INSTALL NEW WALK-IN BOX. HANG THE NEW DOOR AND ENSURE THAT ALL HARDWARE FUNCTIONS...	N/A	N/A	N/A	N/A	N/A	PS	PS	PS
29	RETRIEVE ANY FALL PROTECTION NETTING FROM THE ROOF MEMBERS, AND REATTACH IT TO THE TOP OF THE WALK-IN BOX AS DESCRIBED ON THE PRINTS.	N/A	N/A	N/A	N/A	N/A	GC	RC	N/A
30	REATTACH ANY ITEMS PREVIOUSLY MOUNTED TO THE EXTERIOR OF THE WALK-IN BOX THAT WERE TEMPORARILY SUPPORTED DURING THE WALK-IN BOX REPLACEMENT. (FOR EXAMPLE PANEL BOARDS, EMS BACKBOARDS ETC.)	N/A	N/A	N/A	N/A	N/A	GC	RC	GC
31	INSTALL NEW PROTECTION DEVICES AS INDICATED ON THE PRINTS. REINSTALL ANY EXISTING PROTECTION DEVICES OR STRUCTURES AS REQUIRED. ENSURE THAT ANY UNDISTURBED PROTECTION DEVICES ARE FIXED SECURELY.	GC	RC	GC	RC	GC	RC	GC	RC
32	INSTALL THE NEW EVAPORATORS (MECHANICAL, ELECTRICAL, PLUMBING AND CONTROLS) AND CONTROL PANELS AS DETAILED ON THE PRINTS.	N/A	N/A	N/A	N/A	RC	RC	RC	RC
33	EVAUATE AND PRESSURE TEST THE NEW EVAPORATORS AND ANY PIPING MODIFIED DURING THE WORK.	N/A	N/A	N/A	N/A	RC	RC	RC	RC
34	INSTALL AND COMMISSION REFRIGERANT LEAK DETECTION SYSTEM AS NOTED ON THE PROJECT PRINTS.	N/A	N/A	N/A	N/A	RC	RC	RC	RC
35	INSTALL / MODIFY ALL UTILITIES FOR FINAL BOX CONFIGURATION, (CONDENSATE PIPING, CONDUITS, J-BOX, LIGHTING, FIRE SUPPRESSION ETC.) INSTALL CONDUIT FOR APX CABLING. SEAL ALL PENETRATIONS PER SPECIFICATION.	RC	RC	GC	RC	GC	RC	GC	RC
36	SWITCH ON THE REFRIGERATION, LIGHTING AND OTHER SYSTEMS WITHIN THE WALK-IN.	RC	RC	RC	RC	RC	RC	RC	RC
37	COMMISSION THE NEW EVAPORATORS, VALVES AND CONTROLS AS REQUIRED. CHECK AND ADJUST MECHANICAL TVX SUPERHEATS TO OEM RECOMMENDATIONS AND EPR SETTINGS PER NEW LEGEND.	N/A	N/A	N/A	N/A	RC	RC	RC	RC
38	CARRY OUT ANY CONTROLS PARAMETER CHANGES.	N/A	N/A	N/A	N/A	EMS	EMS	EMS	EMS
39	CARRY OUT ANY CONTROLS PARAMETER CHANGES AND PERFORM REMOVE CHECKOUT.	N/A	N/A	N/A	N/A	RC	RC	RC	RC
40	FURNISH CONTROLS SUPPORT TO THE INSTALLING CONTRACTOR.	N/A	N/A	N/A	N/A	EMS	EMS	EMS	EMS
41	NOTIFY WMT BUILDING CONTROLS THAT THE WALK-IN BOX IS RUNNING AND ONLINE.	RC	RC	RC	RC	RC	RC	RC	RC
42	REINSTALL / RECOMMISSION THE APX REPEATER DEVICE.	WMT	WMT	WMT	WMT	WMT	WMT	WMT	WMT
43	INSTALL NEW SHELVING / RACKING AS INDICATED ON THE PLANS. RE-INSTALL RACKING AS NECESSARY.	WMT	RC	GC	RC	GC	RC	GC	RC
44	ANCHOR RACKING AS INDICATED ON THE PLANS.	GC	RC	GC	RC	GC	RC	GC	RC
45	INSTALL CIRCUIT LABELS TO THE NEW WALK-IN BOX CONTROLLERS AND EVAPORATORS AS REQUIRED.	RC	RC	RC	RC	RC	RC	RC	RC
46	CARRY OUT A THOROUGH LEAK TEST ON ALL WELDED AND MECHANICAL JOINTS INSTALLED OR DISTURBED DURING THE PROJECT.	RC	RC	RC	RC	RC	RC	RC	RC
47	HANDOVER THE COMPLETED WALK-IN BOX TO THE STORE. (WALK-IN BOX MUST BE CLEAN, AT OPERATIONAL TEMPERATURE AND FULLY FUNCTIONAL)	GC	RC	GC	RC	GC	RC	GC	RC
48	RE-LOCK PRODUCT INTO THE WALK-IN BOX.	WMT	WMT	WMT	WMT	WMT	WMT	WMT	WMT
49	REMOVE ALL OF THE OLD WALK-IN BOX PANELS FROM SITE (IF APPLICABLE). NOTE: WORK REFRIGERANT TO HALF FULL ON ALL WALK-IN BOX PANELS FROM TEXAS PROJECTS.	GC/PS	RC/PS	GC/PS	RC/PS	GC/PS	RC/PS	GC/PS	RC/PS
50	REMOVE THE OLD LEGENDS. INSTALL REPLACEMENT LEGENDS AS SUPPLIED BY THE EOR / OEM. PROVIDE WMT, TVX, THERMAL BREAKS FOR ANY AFFECTED ELECTRICAL PANELS.	RC	RC	RC	RC	RC	RC	RC	RC
51	SHUT DOWN THE ARRANGE FOR THE REMOVAL OF ANY TEMPORARY, REFRIGERATED STORAGE. AFTER ALL CHANGES HAVE BEEN MADE TO A RACK, REMOVE ANY COMPRESSOR SUCTION FILTERS / SOCKS AND REPLACE THE RACK LIQUID LINE FILTERS. LEAVE THE OLD FILTERS / DRIERS IN THE RACK HOUSE TO BE INSPECTED BY THE MCM.	WMT	WMT	WMT	WMT	WMT	WMT	WMT	WMT
52	SUBMIT REQUIRED VERISAE AND OTHER REGULATORY FORMS AS REQUIRED BY THE END OF COMMISSIONING WEEK. COMPLETED VERISAE FORMS ARE TO BE EMAILED TO MCEOUP@WAL-MART.COM.	RC	RC	RC	RC	RC	RC	RC	RC
53	REMOVE ALL OF THE OLD CASES AND CLEAR SITE OF ALL TOOLS, UNUSED INSTALLATION MATERIALS AND TRASH.	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS
54	CLEAR SITE OF ALL TOOLS, UNUSED INSTALLATION MATERIALS AND TRASH.	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS	RC/PS

**REFRIGERATION PIPE RE-INSULATION**

\*\*\*NOTE\*\*\*  
THIS DOCUMENT IS INTENDED TO DESCRIBE IMPORTANT ELEMENTS OF THIS PROJECT AND TO DEFINE THE RESPONSIBLE PARTIES FOR THIS WORK STREAM. IT IS NOT MEANT TO BE AN EXHAUSTIVE SOURCE OF INFORMATION OR A COMPLETE SCOPE OF WORK. IT SHOULD BE READ AND USED IN CONJUNCTION WITH ADDITIONAL, DETAILED INFORMATION IN THE WALMART REALTY ONE BEST WAY STANDARDS LIBRARY, AND IN PUBLICATIONS AVAILABLE FROM THE MANUFACTURER.

#	SCOPE OF WORK	RESPONSIBLE PARTY	
		REMODEL	CAPEX
1	FURNISH AND INSTALL ALL MATERIALS NECESSARY TO COMPLETE THE WORK.	RC	RC
2	COORDINATE THE INSTALLATION TIME WITH STORE MANAGEMENT. OBTAIN HOT WORK PERMITS AS REQUIRED.	RC	RC
3	NOTIFY THE WMT BUILDING CONTROLS TEAM AND ADVISE THEM WHICH SYSTEMS AND WHICH CASES WILL BE IMPACTED BY THE WORK.	RC	RC
4	WHEN REPLACING MULTIDECK AND /OR GLASS DOOR CASES, AND REINSULATE EXISTING PIPEWORK, THE REFRIGERATION PIPING BEHIND THE CASES SHOULD BE RE-INSULATED. THIS APPLIES TO ALL PIPING...	RC	RC
5	CONFIRM WITH STORE MANAGEMENT THAT THE WORK IS COMPLETE AND ALL SYSTEMS IMPACTED BY THE WORK ARE FULLY FUNCTIONAL.	RC	RC
6	CLEAR SITE OF ALL TOOLS, OLD INSULATION, UNUSED INSTALLATION MATERIALS AND TRASH.	RC	RC

**KE2 THERM EVAPORATOR CONTROL PANEL INSTALLATION**

\*\*\*NOTE\*\*\*  
THIS DOCUMENT IS INTENDED TO DESCRIBE IMPORTANT ELEMENTS OF THIS PROJECT AND TO DEFINE THE RESPONSIBLE PARTIES FOR THIS WORK STREAM. IT IS NOT MEANT TO BE AN EXHAUSTIVE SOURCE OF INFORMATION OR A COMPLETE SCOPE OF WORK. IT SHOULD BE READ AND USED IN CONJUNCTION WITH ADDITIONAL, DETAILED INFORMATION IN THE WALMART REALTY ONE BEST WAY STANDARDS LIBRARY, AND IN PUBLICATIONS AVAILABLE FROM THE MANUFACTURER.

#	SCOPE OF WORK	RESPONSIBLE PARTY					
		BASIC PANEL		STANDARD PANEL			
		SELF PERFORM	REMODEL	CAPEX	SELF PERFORM	REMODEL	CAPEX
1	FURNISH THE NEW KE2 THERM EVAPORATOR CONTROL PANELS, SENSORS AND OTHER DEVICES AS REQUIRED TO COMPLETE THE PROJECT.	WMT	WMT	WMT	WMT	WMT	WMT
2	FURNISH AND INSTALL ALL REFRIGERANT PIPING, AND ALL FIELD INSTALLED REFRIGERATION VALVES NECESSARY TO COMPLETE THE WORK.	WMT	RC	RC	WMT	RC	RC
3	FURNISH ALL CONTROLS CABLING AS NECESSARY TO COMPLETE THE WORK. (24 VOLTS OR LESS)	WMT	EMS	EMS	WMT	EMS	EMS
4	INSTALL AND TERMINATE CONTROLS WIRING (24 VOLTS OR LESS) AS DETAILED ON THE PRINTS.	WMT	RC	RC	WMT	RC	RC
5	FURNISH AND INSTALL ALL ELECTRICAL POWER CABLING FROM POWER SOURCE.	WMT	GC	RC	WMT	GC	RC
6	TERMINATE POWER CABLES TO THE KE2 PANELS.	WMT	RC	RC	WMT	RC	RC
7	COORDINATE THE INSTALLATION TIME WITH STORE MANAGEMENT. PREFABRICATE AS MUCH OF THE ELECTRICAL CONDUIT AS POSSIBLE. ROUTE POWER AND CONTROLS CABLES AND MOUNT ANY NEW DEVICES PRIOR TO FINAL CONNECTIONS BEING MADE IN ORDER TO REDUCE THE AMOUNT OF "DOWN TIME" NEEDED TO COMPLETE THE INSTALLATION.	WMT	GC	RC	WMT	GC	RC
8	IF THE NEW KE2 PANEL IS BEING RETROFITTED TO AN EXISTING WALK-IN BOX, ENSURE THAT THE WALK-IN BOX DOOR IS KEPT CLOSED AS MUCH AS POSSIBLE DURING THE TIME IN WHICH THE CONVERSION WORK IS BEING...	WMT	RC	RC	WMT	RC	RC
9	NOTIFY THE WMT BUILDING CONTROLS TEAM AND ADVISE THEM WHICH SYSTEM AND WHICH WALK-IN BOX WILL BE IMPACTED BY THE WORK.	WMT	RC	RC	WMT	RC	RC
10	REMOVE THE BASIC KE2 EVAPORATOR CONTROL PANEL ON A WALL INSIDE THE RACK HOUSE. NOTE THAT PANELS MUST BE INSTALLED WITH NEC REQUIRED CLEARANCES.	WMT	RC	RC	N/A	N/A	N/A
11	MOUNT THE STANDARD KE2 EVAPORATOR CONTROL PANEL ON THE EXTERNAL WALL OF THE FREEZER TO WHICH THE CONTROLS ARE CONNECTED. INSTALL THE PANEL ON THE DOOR WALL OF THE FREEZER IN AN ACCESSIBLE POSITION THAT IS OUT OF THE WAY OF TRAFFIC. DO NOT DAMAGE THE PANEL. NOTE THAT PANELS MUST BE INSTALLED WITH NEC REQUIRED CLEARANCES.	N/A	N/A	N/A	WMT	RC	RC
12	REMOVE THE (CONTROL) PANEL FOR THE EVAPORATOR CONTROL PANEL, EVAPORATOR FANS AND THE SENSOR FROM THE EXISTING CONTROL PANEL. USING THE WIRING DIAGRAMS SUPPLIED WITH THE KE2 THERM TAPING KIT, SPLICE INTO THE EXISTING WIRING AND CONNECT THEM TO THE CORRECT TERMINALS IN THE KE2 THERM PANEL. THE EXISTING WIRING SHOULD BE CONNECTED TO THE KE2 THERM PANELS VIA THE EXISTING CIRCUIT COILS.	WMT	RC	N/A	N/A	N/A	N/A
13	INSTALL A NEW MULTICOIL CABLE FROM THE RACK HOUSE TO THE WALK-IN BOX TO TERMINATE THE NEW RETURN AIR SENSOR. TWO DEFROST TERMINATION POINTS ARE REQUIRED. NOTE THAT ALL KE2 SUPPLIED CONTROL WIRING IS FOR CODED.	WMT	RC	RC	N/A	N/A	N/A
14	REMOVE THE EXISTING DEFROST CIRCUIT TO POWER THE KE2 THERM PANEL.	N/A	N/A	N/A	WMT		